

TRUFAST® Walls Fastening Systems for ROCKWOOL™ Mineral Wool



Plasti-Grip® PMF Anchor

- For masonry applications
- Easy installation
- Pre-drill with 5/16" masonry bit
- Tap flush with hammer
- Prevents thermal-bridging
- No screws or adhesives required

PMF Size	Insulation Thickness
2"	1/2" - 3/4"
2 3/4"	1" - 1 1/2"
3 1/2"	1 1/2" - 2"
4 1/2"	2 1/2" - 3"
5 3/8"	3 1/2" - 4"
6 1/4"	4 1/2" - 5"



Grip-Lok® MW Plate

- Secures up to 5" of mineral wool
- Shoot it, screw it, or nail it
- All substrates including wood, metal and masonry
- Unlike adhesive pins, provides permanent attachment
- Mill galvanized to prevent corrosion
- Curled sides provide rigidity and prevent sharp edges at perimeter
- Optional gasketed screw helps seal penetration of WRB / air barrier



Grip-Deck TubeSeal™

- Seals blind fastener penetrations of a WRB or air-barrier
- Available in multiple lengths for various insulation thicknesses
- UV resistant polyurethane tube construction is suitable for all weather climates
- Available pre-assembled with various Grip-Deck® screws including SDS (self-drilling) or HiLo thread with various Rodenhouse washers.



Thermal-Grip® Masonry Veneer Anchor

- Maintains air-barrier performance
- Uniquely designed for minimal thermal-bridging
- Available for all substrates
- Wire tie design allows for easy one hand assembly



Thermal-Grip® IFS

- Rapidly attaches rigid insulation and mineral wool to concrete, masonry, and tilt up / precast walls
- Large 2.25" diameter washer head secures insulation
- Anchor lengths available from 1" to 6"
- Pins available for attaching insulation to concrete / CMU
- Pins available for attaching insulation to 12-18 gauge steel studs



TRUFAST® Walls Fastening Systems for ROCKWOOL™ Mineral Wool

