

# TRUFAST® Fastening Systems for ROCKWOOL Smartrock®



## Plasti-Grip® PMF Anchor

- For masonry applications
- Easy installation
- Pre-drill with 5/16" masonry bit
- Tap flush with hammer
- Prevents thermal-bridging
- No screws or adhesives required

PMF Size	Insulation Thickness
2"	1/2" - 3/4"
2 3/4"	1" - 1 1/2"
3 1/2"	1 1/2" - 2"
4 1/2"	2 1/2" - 3"
5 3/8"	3 1/2" - 4"
6 1/4"	4 1/2" - 5"



## Thermal-Grip® IFS

- Rapidly attaches rigid insulation and mineral wool to concrete, masonry, and tilt up / precast walls
- Large 2.25" diameter washer head secures insulation
- Anchor lengths available from 1" to 6"
- Pins available for attaching insulation to concrete / CMU



## Thermal-Grip® ci Prong Washer

- 2" dia. solid cap washer for use with Grip-Deck® ci screws
- Pre-spotting prongs for easy on-the-wall screw assembly
- Flattens on surface of the insulation without tearing facer

